

C Cutter Instructions

03402, 03412, 03413, 03414

Snap the cutter onto the copper tubing in the location where cut is desired. Turn the spring-loaded tubing cutter in the direction of the arrows etched onto the tool. This permits the springs on the cutter wheel to tighten with each rotation around the pipe. Turn until cut is complete.

Replacement Cutter Wheel: #03376 TCKCW or 2-pack #63376 2PK-TCKCW

Each cutter fits just one size of tubing: 1/2", 3/4", or 1"



Reed Manufacturing
1425 West 8th Street
Erie, PA 16502 USA
Phone: 800-666-3691 or 814-452-3691
Fax: 800-456-1697 or 814-455-1697
www.reedmfgco.com

TCKINST-0320