

UPC 3.5 GALLON WATER TANK

UPCH20TANK
#97577

WARNING: IMPROPER USE OR FAILURE TO FOLLOW INSTRUCTIONS CAN RESULT IN EXPLOSIVE FAILURE WITH MAJOR INJURIES. FOR SAFE USE OF THIS PRODUCT, READ AND FOLLOW ALL INSTRUCTIONS BEFORE USE.

Operation Instructions

Caution:

- **Do not** leave a pressurized tank in the hot sun.
- Do not store tanks with water inside.
- Always wear eye protection when tank is pressurized.
- Never use any tool to remove pump if tank is pressurized.
- Never stand with face or body over top of tank when pumping.
- Never pressurize tank by any means other than the original pump.
- Do not attempt to modify or repair this product.

Pre-Use Check:

- **First Time Use:** Install hose onto tank by pushing the clear tube onto the nipple at the top of tank and tightening the hose clamp over the joint.
- **Check** tightness of hose clamp with screwdriver.
- Inspect hose for deterioration, crack, softness, or brittleness. If any of these conditions are found, replace them with original manufacturer's equipment.
- Inspect interior and exterior of tank for signs of deterioration (i.e., rust and/or pitting) of body and bottom. Replace tank if any of these signs exist.
- **Do not** attempt to patch leaks, etc., as this could result in serious injury.
- Follow filling and pressurizing instructions.
- Pump plunger only 8-10 strokes and inspect for leaks. Direct shut off away from operator and open to make sure discharge is not clogged.
- If unit passes this test, proceed with filling and pressurizing instructions.

Filling & Pressurizing Instructions:

- To fill the water tank, remove pump from the tank by turning counterclockwise.
- Fill tank 7/8 full.
- To reassemble, insert the pump back into the tank. Rotate clockwise until tight.
- Push down on the handle and rotate until the handle tabs are free from the collar.
- Pump the plunger up and down until the plunger is difficult to push.

WARNING: This tank is now under pressure and dangerous. Always wear protective eye gear when tank is pressurized.

Pressure Release Instructions:

WARNING: To prevent injury from an ejected pump or water, the unit must be placed on its side with the top directed away from the operator. With the hose outlet positioned upward, the tubing must be directed away from the operator, and the shut-off valve opened to fully release all pressure and water. With all the pressure released and the top of the tank pointed away from the operator, it is safe to remove the pump.

Tank Care, Storage & Maintenance:

- Remove pump and empty sprayer.
- Store tank and pump— with pump removed and shut-off locked open - upside down in warm, dry location.
- Twice a year - oil pump by applying 10-12 drops of light oil down the pump rod through the opening in the cover.
- Apply a small amount of Vaseline or other similar lubricant to pump threads.



WARNING: Cancer and Reproductive Harm
www.P65Warnings.ca.gov



PIPE TOOLS & VISES
SINCE 1896

Reed Manufacturing, Erie, PA USA
800-666-3691 • +1 814-452-3691
reedsales@reedmfgco.com
www.reedmfgco.com